

**INSTRUCTIONS FOR INSTRUCTIONS FOR SCANNING THE NEW 3ABN FREQUENCY
GLOBO RECEIVER**

**Please note that these instructions are for Globo receiver's which has no HEALING logo on the bottom right of the screen.
PLEASE BE AWARE – THESE INSTRUCTIONS WILL BE INEFFECTIVE IF YOU HAVE PERFORMED A FACTORY RESET
Please follow the steps as listed. Do not change anything unless specified. Please do not perform a factory reset.
Christian Satellite is not liable for any damage or loss of programming that may be incurred by following these instructions.**

STEP 1 - Scanning the frequency 12546 for the new location of 3ABN

- A. Turn on your TV and receiver
- B. By using your remote press the **MENU** button and scroll **RIGHT** to **INSTALLATION**
- C. Next scroll down and select **CHANNEL SEARCH** and press the **OK** button. The receiver may request a password. Enter **9402** by using the numbers on the remote or if that does not work try **0000**
- D. Next highlight **ANTENNA** and press the **OK** button
- E. Next scroll down in the list and select highlight number **15** and press the **OK** button
- F. Please make sure that **SATELLITE** is displaying **OPTUS B3** if not go back to **ANTENNA** and press the right or left button until you see **OPTUS B3**
- G. Next scroll down to **TRANSPONDER** and press the **BLUE (AUDIO R\L)** button to **ADD NEW TP**
- H. Next scroll down to **FREQUENCY** and enter **12546** by using the numbers on the remote
- I. Next scroll down to **SYMBOL RATE** and enter **22500** by using the numbers on the remote
- J. Next scroll down to **POLARIZATION** and press the left or right button on the remote to select **VER**
- K. Next scroll down to **SEARCH MODE** and press the left or right button on the remote to select **FTA**
- L. Next scroll down to **SEARCH NETWORK** and press the left or right button on the remote to select **NO**
- M. Next scroll down and highlight **SEARCH TP** and press the **OK** button
- N. When the receiver is finished scanning a **CHANNEL SEARCH** window will appear on the screen highlight **EXIT** and press the **OK** button
- O. Next press the **EXIT** button to exit channel search.

STEP 2 – Organising channels

- A. Scroll to **CHANNEL MANAGER** and select **TV CHANNEL** and press the **OK** button. The receiver may request a password. Enter **9402** by using the numbers on the remote or if that does not work try **0000**
- B. Next press the **YELLOW** button on the remote and you should see **MOVE** displayed in yellow on the top of the screen.
- C. Next scroll **UP** or **DOWN** through the list on the right of the screen and then press the **OK** button on the channels you wish to move
- D. Next by using the **UP** and **DOWN** arrow on the remote and scroll to where you would like the channel to appear in the list and press the **OK** button
- E. Continue this with the various channels until you are satisfied with the list.
- F. Once you are finished press the **EXIT** button on the remote twice to exit out of the menu and the receiver will save the changes.

The Christian Channels:

1. Hope Channel
2. 3ABN
3. Trinity
4. God TV
5. JCTV
6. The Church Channel
7. EWTN
8. Daystar TV
9. Smile of a Child
10. Inspiration Network
11. AON (Apostolic Oneness Network)

Other Channels of Interest

1. Press TV
2. Russia Today