

**INSTRUCTIONS FOR SCANNING THE NEW 3ABN FREQUENCY
STGOLD ST-2000F**

PLEASE BE AWARE – THESE INSTRUCTIONS WILL BE INEFFECTIVE IF YOU HAVE PERFORMED A FACTORY RESET
Please follow the steps as listed. Do not change anything unless specified. Please do not perform a factory reset.
Christian Satellite is not liable for any damage or loss of programming that may be incurred by following these instructions.

STEP 1 - Scanning the frequency 12546 for the new location of 3ABN

- A. Turn on your TV and receiver. Press the **MENU** button on the remote.
- B. From the **MAIN MENU** select **INSTALLATION** and press the **OK** button.
- C. The receiver will request a password. Enter **9402** or if that does not work try **0000**
- D. Once you are in the **INSTALLATION** menu, highlight **SCAN TRANSPONDER** and press the **OK** button.
- E. Next scroll down to **DISH** and ensure it is displaying **1 OPTUS B3**.
- F. Next scroll down to **FREQUENCY** and enter **12546** by using the numbers on the remote.
- G. Next scroll down to **POLARITY** and press left or right on the remote and select **VERTICAL**.
- H. Next scroll down to **SYMBOL RATE** and enter **22500** by using the numbers on the remote.
- I. Next scroll down to **CODE RATE** and select **3/4**.
- J. Next scroll down to **SCAN MODE** and select **FREE CHANNEL**.
- K. Next scroll down to **NETWORK SEARCH** and select **DISABLE**.
- L. Next press **OK** and the receiver will begin searching for the channels. Once the search is completed the receiver will display a message **DO YOU WANT TO SAVE CHANGES?**
- M. Highlight **YES** and press the **OK** button.

STEP 2 – Organising channels

- A. Select **EDIT CHANNEL** and press the **OK** button. The receiver will request a password. Enter **9402** or if that does not work try **0000** press the **OK** button
- B. On the bottom left of the screen, highlight **MOVE** and press the **OK** button. Ensure a tick is next to **MOVE**
- C. Next scroll through the channel list on the right and press the **OK** Button on the channel that you would like to move. Now scroll **UP** or **DOWN** and move the channel to where you would like it to appear in the list and then press the **OK** button. Continue this with the various channels until you are satisfied with the list.
- D. Once you are finished press the **EXIT** button on the remote and the receiver will display a message **DO YOU WANT TO SAVE CHANGES?** Highlight **YES** and press the **OK** button.
- E. Now press the **EXIT** button twice

The Christian Channels:

1. Hope Channel
2. 3ABN
3. Trinity
4. God TV
5. JCTV
6. The Church Channel
7. EWTN
8. Daystar TV
9. Smile of a Child
10. Inspiration Network
11. AON (Apostolic Oneness Network)

Other Channels of Interest (non-christian)

1. Press TV
2. Russia Today