

**INSTRUCTIONS FOR SCANNING THE NEW 3ABN FREQUENCY  
SOUTHERN CROSS DVBS-2888**

**PLEASE BE AWARE – THESE INSTRUCTIONS WILL BE INEFFECTIVE IF YOU HAVE PERFORMED A FACTORY RESET**  
**Please follow the steps as listed. Do not change anything unless specified. Please do not perform a factory reset.**  
**Christian Satellite is not liable for any damage or loss of programming that may be incurred by following these instructions.**

**STEP 1 - Scanning the frequency 12546 for the new location of 3ABN**

1. Turn on your TV and receiver. Press the **MENU** button on the remote.
2. From the **MAIN MENU** scroll left or right and highlight **INSTALLATION**
3. Next scroll down and highlight **TP SCAN** and press the **OK** button. The receiver may request a password. Enter **0000**. If **0000** is not working you will need to contact your installer for the password
4. Next scroll down and highlight **SATELLITE** and press the **OK** button
5. Next scroll up or down in the list of satellite and highlight **OPTUS B3 152E** and press the **OK** button
6. Next scroll down and highlight **TP INDEX** and scroll left or right and select **1/19**
7. Next scroll down and highlight **TP FREQUENCY** and by using the number keys on the remote enter **12546**
8. Next scroll down and highlight **SYMBOL RATE** and by using the number keys on the remote enter **22500**
9. Next scroll down and highlight **POLARITY** and by using **V+/V-** key on the remote select **V**
10. Next scroll down and highlight **SCAN MODE** and by using **V+/V-** key on the remote select **FREE**
11. Next scroll down and highlight **SEARCH** and press the **OK** button and the receiver will start scanning
12. Next press the **EXIT** button to exit the **TP SCAN** window

**STEP 2 – Organising channels**

- A. From the **MAIN MENU** scroll left by using the **V+/V-** button and highlight **CHANNEL**
- B. Next scroll down and highlight **TV CHANNEL LIST** and press the **OK** button. The receiver may request a password. Enter **0000**
- C. Next scroll through the channel list and press the number **2** key button on the channel that you would like to move. Now scroll **UP** or **DOWN** and move the channel to where you would like it to appear in the list and press **OK**. Continue this with the various channels until you are satisfied with the list.
- D. Once you are finished press the **EXIT** button on the remote until you are out of the main menu.

**The Christian Channels:**

1. Hope Channel
2. 3ABN
3. Trinity
4. God TV
5. JCTV
6. The Church Channel
7. EWTN
8. Daystar TV
9. Smile of a Child
10. Inspiration Network
11. AON (Apostolic Oneness Network)

**Other Channels of Interest (non-christian)**

1. Press TV
2. Russia Today