

**INSTRUCTIONS FOR SCANNING THE NEW 3ABN FREQUENCY  
STRONG SRT 3650**

**PLEASE BE AWARE – THESE INSTRUCTIONS WILL BE INEFFECTIVE IF YOU HAVE PERFORMED A FACTORY RESET**  
**Please follow the steps as listed. Do not change anything unless specified. Please do not perform a factory reset.**  
**Christian Satellite is not liable for any damage or loss of programming that may be incurred by following these instructions.**

**STEP 1 - Scanning the frequency 12546 for the new location of 3ABN**

- A.** Press the **MENU** button and scroll to and highlight **INSTALLATION** and press the **OK** button. The receiver may request a password. Enter **9402** or if that does not work try **0000**
- B.** Next highlight **MANUAL SEARCH** and press the **OK** button
- C.** Next highlight **SATELLITE NAME** press the **OK** button and then a list will pop up then scroll **UP** or **DOWN** and highlight **29 OPTUS B3** and press the **OK** button
- D.** Next scroll down and highlight **FREQUENCY** and enter **12546** using the numbers on the remote
- E.** Next scroll down and highlight **SYMBOL RATE** and enter **22500** using the numbers on the remote
- F.** Next scroll down and highlight **POLARIZATION** and scroll **LEFT** or **RIGHT** by using the remote and select **VER**
- G.** Next scroll down and highlight **SEARCH TYPE** and scroll **LEFT** or **RIGHT** and select **FTA**
- H.** Next scroll down and highlight **NIT SEARCH** and scroll **LEFT** or **RIGHT** and select **OFF**
- I.** **Please check setting A to H before continuing**
- J.** Next press the **BLUE (SUBTITLE)** button on your remote and the receiver will begin searching for the channels

**STEP 2 – Organising channels**

- A.** On the bottom of the screen scroll **LEFT** or **RIGHT** and highlight **MOVE**.
- B.** Next scroll **UP** or **DOWN** in the list of channels and press the **OK** button on the channel that you would like to move.
- C.** Next press the **RED (AUDIO)** button and a **v** should appear in the front of the channel
- D.** Now scroll **UP** or **DOWN** and move the channel to where you would like it to appear in the list and then press the **OK** button. Continue **B, C** and **D** with the various channels until you are satisfied with the list.
- E.** Once you are finished press the **EXIT** button on the remote and the receiver will save the changed and exit out of the installation menu.

**The Christian Channels:**

1. Hope Channel
2. 3ABN
3. Trinity
4. God TV
5. JCTV
6. The Church Channel
7. EWTN
8. Daystar TV
9. Smile of a Child
10. Inspiration Network
11. AON (Apostolic Oneness Network)

**Other Channels of Interest (non-christian)**

1. Press TV
2. Russia Today