

**INSTRUCTIONS FOR SCANNING THE NEW 3ABN FREQUENCY  
STRONG SRT 4650**

**PLEASE BE AWARE – THESE INSTRUCTIONS WILL BE INEFFECTIVE IF YOU HAVE PERFORMED A FACTORY RESET**  
**Please follow the steps as listed. Do not change anything unless specified. Please do not perform a factory reset.**  
**Christian Satellite is not liable for any damage or loss of programming that may be incurred by following these instructions.**

**STEP 1 - Scanning the frequency 12546 for the new location of 3ABN**

- A.** Turn on your TV and receiver. Press the **MENU** button on the remote.
- B.** From the **MAIN MENU** highlight **INSTALLATION** and press the **OK** button. The receiver may request a password. Enter **9402** or if that does not work try **0000**
- C.** Next scroll down and highlight **MANUAL SCAN** and press the **OK** button
- D.** Next scroll down and highlight **SATELLITE** and scroll left or right and select **OPTUS B3/KU**
- E.** Next press the **GREEN (AUDIO)** button on the remote
- F.** Next highlight **FREQUENCY** and enter **12546** by using the numbers on the remote
- G.** Next highlight **SYMBOL RATE** and enter **22500** by using the numbers on the remote
- H.** Next highlight **POLARIZATION** and scroll left or right using the remote and select **V**
- I.** Next highlight **SEARCH TYPE** and scroll left or right and select **FTA ONLY**
- J.** Next highlight **NETWORK SEARCH** and scroll left or right and select **OFF**
- K.** **Please check setting E to I before continuing**
- L.** Next press the **OK** button and the receiver will begin searching for the channels
- M.** Once the scan has finished press the **EXIT** button once

**STEP 2 – Organising channels**

- A.** From the **MAIN MENU** scroll **UP** highlight **MOVE CHANNELS** and press the **OK** button.
- B.** Next scroll through the channel list and press the **OK** button on the channel that you would like to move. Now scroll **UP** or **DOWN** and move the channel to where you would like it to appear in the list and press **OK**. Continue this with the various channels until you are satisfied with the list.
- C.** Once you are finished press the **EXIT** button on the remote and the receiver will display a message **“Settings were changed DO YOU WANT TO SAVE?”** Highlight **YES** in yellow and press the **OK** button.
- D.** Now press the **EXIT** button twice